




GUIDE TO **ADDING SPACE GUARDS TO YOUR ELEVATOR**



Hazard Warning

Young children can become entrapped in the space between the exterior landing (hoist-way) door and the interior elevator car door or gate if there is a hazardous gap and suffer serious injuries or death when the elevator is called to another floor.

Q: Do I need to disable my elevator immediately?

Yes, if you have young children in your home (or if your home is visited by or rented to families with young children). You should immediately disable the elevator or block young children's access to the elevator until the issue is addressed. Young children should never be allowed to use an elevator unattended or to play in or near an elevator.

No, if you do not have young children in your home (or if your home is not visited by or rented to families with young children). You may continue to operate your elevator until space guards are installed. We urge you to promptly remedy any gaps that may exist behind your landing doors.

1. MEASURE


Conduct measurements and enter measurements in the fields provided. Be sure to note the floor on which you conduct the measurements. ([Measurement Video](#))

Landing door to running clearance



Measure and write down the distances between the landing door and the running clearance on each of the left side and the right side of the landing door.

Door stopper to door stopper measurement



	Landing Door to Running Clearance	Door Stopper to Door Stopper
FLOOR 1	<input type="text" value="INCHES"/>	<input type="text" value="INCHES"/>
FLOOR 2	<input type="text" value="INCHES"/>	<input type="text" value="INCHES"/>
FLOOR 3	<input type="text" value="INCHES"/>	<input type="text" value="INCHES"/>
FLOOR 4	<input type="text" value="INCHES"/>	<input type="text" value="INCHES"/>
FLOOR 5	<input type="text" value="INCHES"/>	<input type="text" value="INCHES"/>
FLOOR 6	<input type="text" value="INCHES"/>	<input type="text" value="INCHES"/>

2. REQUEST SPACE GUARDS

Record the correct measurements and fill in the [door gap recall form](#). If door gap is not in compliance, we will send you space guards free of charge.

3. INSTALL SPACE GUARDS

Watch the [Installation Video](#) and install the custom-sized and labeled space guards. We will provide assistance with space guard installation upon request.

CONTACT US

MAILING ADDRESS

2910 Kerry Forest Pkwy, D4-1,
Tallahassee, FL 32309

DIRECT CONTACT

Toll Free Telephone: 800.832.2004
Local: 850.906.3054

Office Hours:

General Business: Monday - Friday 8 AM - 5 PM Eastern Standard Time

Client Support: Mon.-Fri. 8 AM - 7 PM EST, Sat. 9 AM - 5 PM EST, Sun. 11 AM - 5 PM EST

*Excluding Holidays